



MCREE'S PRECISION REAR STOCK PACK

Our REAR STOCK PACK is universal and can be configured for right or left handed shooters. Total weight is 5 ounces and is proudly made in the USA by Tactical Tailor.

Instructions below include installation and how to change the configuration. Thank you for purchasing this product and supporting our effort to keep jobs in the USA.

INSTALLATION:

For optimal fit and function, the REAR STOCK PACK should cover the entire cheek piece from front to rear. Only install the REAR STOCK PACK after you have set your length of pull and set your cheek piece height.

Step 1:

Lay the RSP over the cheek pieces and gauge how much butt pad strap will be needed. (see figure A)

Step 2:

Insert a flat item, such as a ruler or pen, between the fastening loop and break the butt pad strap free from the Velcro. Pull the pad strap from its slot and wrap it around the butt stock pad to the measurement gauged in step 1. (see figure B)

Step 3:

Position the REAR STOCK PACK to the desired placement on the cheek piece, then re-insert the butt pad strap into the fastening loops and secure to the Velcro. This should be a loose fit.

Step 4:

Confirm proper sight alignment with the REAR STOCK PACK installed, then tightly secure the butt pad strap. We recommend that you get an even amount of strap on each side of the REAR STOCK PACK when securing to the Velcro. Installation is now complete and you can head to the range to shoot.

CHANGING SHOOTER CONFIGURATION:

Step:1

Insert a flat item, such as a ruler or pen, between the fastening loop and break the butt pad strap free from the Velcro. Pull the pad strap from its slot and flip the REAR STOCK PACK from right hand to left hand or vice versa.

Step2:

Follow the installation instructions from step 2 to step 4.



MCREES PRECISION
752 CR 174, McCarley, MS. 38943
www.mcreesprecision.net