



MCREE'S PRECISION UNS MOUNT



Follow the UNS Device; manufactures guide lines for correct spacing between the day optic and the UNS device.

Torque Specification: 30 inch pounds

Required tools: Torque Wrench capable of 35 to 40 inch pounds, 1/8 Allen drive bit.

We recommend applying a small amount of lubricant to the threads of the fasteners.

To install your UNS Kit, follow the instruction below.

(Step 1) Remove the thread protection screws that are in the mounting holes.

(Step 2) Carefully align the UNS Mount with the mounting holes and then slide the mount downward until you can see the mount holes thru the holes in the mount body. You may have to use a small amount of pressure to do this, these parts are supposed to fit closely.

(Step 3) The pic rail is numbered, the smallest number should be towards the action, largest number toward the muzzle. This keeps the MOA bias in the correct direction.

(Step 4) Using the screws provided with the UNS Mount, (10-32 x 3/8 Button Head, 10 pieces) thread these in to the tapped holes on the fore end.

(Step 5) Now you can apply final torque to the UNS Mount screws. 30 inch pounds per screw.



MCREES PRECISION
752 CR 174, McCarley, MS. 38943
www.mcreesprecision.net